


FUBAG B5200B



FUBAG B5200B Parts List

REF. #	PART #	DESCRIPTION	REF. #	PART #	DESCRIPTION
1	HS2070Z01	HEX SCREW	44	HS2070Z44	CONNECTOR
2	HS2070Z02	SPRING WASHER	45	HS2070Z45	CONNECTOR NUT
3	HS2070Z03	FRONT COVER	46	HS2070Z46	PISTON PIN
4	HS2070Z04	FRONT COVER GASKET	47	HS2070Z47	COMPRESSOR RING
5	HS2070Z05	BALL BEARING	48	HS2070Z48	OIL RING
6	HS2070Z06	OIL SIGHTGLASS	49	HS2070Z49	PIN CLIP
7	HS2070Z07	OIL SIGHTGLASS SEAL	50	HS2070Z50	PISTON
8	HS2070Z08	BREATHER	51	HS2070Z51	CONNECTING ROD
9	HS2070Z09	CRANKCASE	52	HS2070Z52-1	REGULATOR
10	HS2070Z10	BASEPLATE SEAL	53	HS2070Z53	QUICK CONNECTOR
11	HS2070Z11	BASEPLATE	54	HS2070Z54	MOTOR
12	HS2070Z12	SPRING WASHER	55	HS2070Z55	SPRING WASHER
13	HS2070Z13	HEX SCREW	56	HS2070Z56	SCREW
14	HS2070Z14	OIL PLUG	57	HS2070Z57	MOTOR POWER CORD
15	HS2070Z15	CRANKSHAFT	58	HS2070Z58	PULLEY
16	HS2070Z16	BALL BEARING	59	HS2070Z59	KEY
17	HS2070Z17	BEARING SEAT GASKET	60	HS2070Z60	BELT
18	HS2070Z18	OIL SEAL	61	HS2070Z61	FLAT WASHER
19	HS2070Z19	BEARING SEAT	62	HS2070Z62	SCREW
20	HS2070Z20	SPRING WASHER	63	HS2070Z63	GUARD
21	HS2070Z21	HEX SCREW	64	HS2070Z64	PRESSURE GAUGE
22	HS2070Z22	FLYWHEEL	65	HS2070Z65	PRESSURE SWITCH
23	HS2070Z23	FLYWHEEL FLAT WASHER	66	HS2070Z66	SAFETY VALVE
24	HS2070Z24	FLYWHEEL SCREW	67	HS2070Z67	POWER CORD

	4				
25	HS2070Z25	HEX SCREW	68	HS2070Z68	NUT
26	HS2070Z26	SPRING WASHER	69	HS2070Z69-1	TUBE
27	HS2070Z27	CYLINDER GASKET	70	HS2070Z70	ELBOW CONNECTOR
28	HS2070Z28	CYLINDER	71	HS2070Z71	CHECK VALVE
29	HS2070Z29	VALVE PLATE GASKET	72	HS2070Z72	NUT
30	HS2070Z30	VALVE PLATE	74	HS2070Z74-1	EXHAUST PIPE
31	HS2070Z31	VALVE PLATE GASKET	75	HS2070Z75-1	TANK
32	HS2070Z32	VALVE REED	76	HS2070Z76	OBSERVATION HOLE
33	HS2070Z33	VALVE PLATE	77	HS2070Z77-1	FLAT WASHER
34	HS2070Z34	HEAD COVER GASKET	78	HS2070Z78-1	WHEEL
35	HS2070Z35	AIR FILTER	79	HS2070Z79-1	SNAP SPRING
36	HS2070Z36	HEX SCREW	80	HS2070Z80-1	WHEEL COVER
37	HS2070Z37	HEX SCREW	81	HS2070Z81	DRAIN VALVE
38	HS2070Z38	SPRING WASHER	82	HS2070Z82-1	UNIVERSAL WHEEL
39	HS2070Z39	HEAD COVER	83	HS2070Z83-1	SPRING WASHER
40	HS2070Z40	AFTERCOOLER GASKET	84	HS2070Z84-1	HEX NUT
41	HS2070Z41	AFTERCOOLER	85	HS2070Z85	BALL VALVE
42	HS2070Z42	SPRING WASHER	86	HS2070Z86-1	SCREW
43	HS2070Z43	HEX SCREW	87	HS2070Z87-1	HANDLE