


# FUBAG DCF 900



# FUBAG DCF 900 Parts List

REF #	PART #	DESCRIPTION	REF #	PART #	DESCRIPTION
1	HS3090BT01	CRANKCASE	50	HS3090BT50	SPRING WASHER
2	HS3090BT02	OIL PLUG 3/8	51	HS3090BT51	BOLT
3	HS3090BT03	OIL SIGHTGLASS SEAL	52	HS3090BT52	1 <sup>st</sup> HEAD COVER
4	HS3090BT04	OIL SIGHTGLASS	53	HS3090BT53	AIR FILTER
5	HS3090BT05	OIL CAP SEAL	54	HS3090BT54	OIL SEAL WASHER
6	HS3090BT06	OIL CAP	55	HS3090BT55	BELT GUARD
7	HS3090BT07	1 <sup>st</sup> CYLINDER GASKET	56	HS3090BT56	SCREW
8	HS3090BT08	STUD BOLT	57	HS3090BT57	FLAT WASHER
9	HS3090BT09	SPRING WASHER	58	HS3090BT58	BELT
10	HS3090BT10	HEX NUT	59	HS3090BT59	KEY
11	HS3090BT11	1 <sup>st</sup> VALVE PLATE GASKET	60	HS3090BT60	PULLEY
12	HS3090BT12	1 <sup>st</sup> VALVE PLATE SET	61	HS3090BT61	SCREW
13	HS3090BT13	1 <sup>st</sup> HEAD COVER GASKET	62	HS3090BT62	SPRING WASHER
14	HS3090BT14	SCREW	63	HS3090BT63	MOTOR
15	HS3090BT15	SPRING WASHER	64	HS3090BT64	MOTOR POWER CORD
16	HS3090BT16	ELBOW	65	HS3090BT65	CONNECTING POWER CORD
17	HS3090BT17	COMPRESSOR NUT	66	HS3090BT66	PRESSURE SWITCH
18	HS3090BT18	AFTERCOOLER	67	HS2065Z64	SAFETY VALVE
19	HS3090BT19	COOLING FIN	68	HS3090BT68	PRESSURE GAUGE(60MM)
20	HS3090BT20	T-SHAPE CONNECTOR	69	HS3090BT69	SIX HOLES CONNECTOR
21	HS3090BT21	1 <sup>st</sup> COMPRESSING RING	70	HS3090BT70	CONNECTOR
22	HS3090BT22	1 <sup>st</sup> OIL RING	71	HS3090BT71	BALL VALVE (1/4)
23	HS3090BT23	1 <sup>st</sup> PISTON	72	HS3090BT72	FEMALE QUICK CONNECTOR

24	HS3090BT2 4	1 <sup>st</sup> PISTON PIN	73	HS3090BT7 3	NUT
25	HS3090BT2 5	1 <sup>st</sup> PIN CLIP	74	HS3090BT7 4	UNLOADING PIPE
26	HS3090BT2 6	1 <sup>st</sup> CONNECTING ROD	75	HS2065Z68	ELBOW CONNECTOR
27	HS3090BT2 7	2 <sup>nd</sup> HEAD COVER	76	HS2080Z69	CHECK VALVE
28	HS3090BT2 8	2 <sup>nd</sup> HEAD COVER GASKET	77	HS3090BT7 7	EXHAUST PIPE
29	HS3090BT2 9	2 <sup>nd</sup> VALVE PLATE SET	78	HS3090BT7 8	TANK
30	HS3090BT3 0	2 <sup>nd</sup> VALVE PLATE GASKET	79	HS2065Z72	OBSERVATION HOLE PLUG
31	HS3090BT3 1	2 <sup>nd</sup> CYLINDER	80	HS2065Z89	BALL VALVE (1/2)
32	HS3090BT3 2	2 <sup>nd</sup> COMPRESSING RING	81	HS3090BT8 1	DRAIN VALVE
33	HS3090BT3 3	2 <sup>nd</sup> OIL RING	82	HS2070Z77	WHEEL
34	HS3090BT3 4	2 <sup>nd</sup> PISTON	83	HS2070Z76	FLAT WASHER
35	HS3090BT3 5	2 <sup>nd</sup> PISTON PIN	84	HS2070Z79	SNAP SPRING
36	HS3090BT3 6	2 <sup>nd</sup> PIN CLIP	85	HS3090BT8 5	STARTER PANEL
37	HS3090BT3 7	2 <sup>nd</sup> CONNECTING ROD	86	HS3090BT8 6	NUT
38	HS3090BT3 8	BALL BEARING	87	HS3090BT8 7	SPRING WASHER
39	HS3090BT3 9	CRANKSHAFT	88	HS3090BT8 8	FLAT WASHER
40	HS3090BT4 0	WOODRUFF KEY	89	HS3090BT8 9	BOLT
41	HS3090BT4 1	BALL BEARING	90	HS3090BT9 0	MAGNETIC STARTER
42	HS3090BT4 2	OIL SEAL	91	HS2070Z81	UNIVERSAL WHEEL (4")
43	HS3090BT4 3	BEARING SEAT GASKET	92	HS2070Z82	FLAT WASHER
44	HS3090BT4 4	BEARING SEAT	93	HS2070Z83	SPRING WASHER
45	HS3090BT4 5	BREATHER	94	HS2070Z84	HEX NUT
46	HS3090BT4 6	FLYWHEEL	95	HS3090BT9 5	2 <sup>nd</sup> CYLINDER GASKET
47	HS3090BT4 7	FLAT WASHER	96	HS3090BT9 6	2 <sup>nd</sup> STAGE EXHAUST PIPE
48	HS3090BT4 8	SCREW	97	HS3090BT9 7	1 <sup>st</sup> CYLINDER
49	HS3090BT4	FLYWHEEL WASHER			