


Model: V63



spare parts list

01 crankcase	18 valve plate	35 connecting rod	52 flywheel flat gasket	68 pressure gauge	84 bolt
02 oil plug	19 valve plate	36 nut	53 bolt	69 connecting bolt	85 protector
03 oil sight seal	20 exhaust limter	37 flat gasket	54 belt guard	70 pressure gauge	86 drain valve
04 oil viewer	21 head cover gasket	38 spring washer	55 bolt	71 safety valve	87 wheel
05 screw	22 head cover	39 bolt	56 flat gasket	72 motor power cord	88 flat gasket
06 spring gasket	23 air filter	40 bearing	57 belt	73 power cord	89 split pin
07 real cover	24 bolt	41 washer	58 key	74 nut	90 air valve
08 real cover gasket	25 spring washer	42 crankshaft	59 motor pulley	75 tube	
09 breather	26 tee connect	43 key	60 motor	76 elbow	
10 cylinder gasket	27 exhaust pipe	44 bearing	61 nut	77 check valve	
11 cylinder	28 exhaust elbow	45 oil seal	62 flat gasket	78 exhaust pipe	
12 spring washer	29 T connect	46 bearing seat gasket	63 spring washer	79 tank	
13 bolt	30 compressor ring	47 bearing seat	64 bolt	80 support	
14 nut	31 oil ring	48 spring washer	65 pressure switch	81 nut	
15 admission valve	32 piston	49 screw	66 air valve	82 spring washer	
16 location pin	33 piston pin	50 breather	67 regulator	83 flat gasket	
17 valve plate gasket	34 pin clip	51 flywheel			